

## **Product Sheet**

### va-Q-case ½ Euro



### **Description**

The va-Q-case 1/2 Euro is a robust multi-use box which consists of a wood plastics sandwich with aluminum fittings on the outside. Inside the outer shell 30 mm and 40 mm va-Q-vip panels are placed which are protected by a stainless steel protective layer. Inside of the volume enclosed by the protective layer cold packs (called va-Q-accus) are placed. The va-Q-case 1/2 Euro has pallet feet and thus is forkliftable.

### **Dimensions**

Outer Dimensions:	800 mm (l)	x 600 mm (w)	x 800 mm (h)
	31.5" (l)	x 23.6" (w)	x 31.5" (h)
Payload capacity (with 14 va-Q-accus):	605 mm (l)	x 410 mm (w)	x 470 mm (h)
	23.8" (l)	x 16.1" (w)	x 18.5" (h)

### **Weight**

Weight without va-Q-accus:	59 kg
	130 lbs